

Connecteur pour servo/capteur :  
GND, V1, Signal



Connecteur pour servo/capteur :  
Signal, V2, GND



Connect +V1 to Servo power

Connect +V2 to Servo power

Corner LEDs  
4 - 3 - 2 - 1

IR photo-transistor outputs  
corner sensors  
1 - 2 - 3 - 4

Left Encoder  
VCC  
1  
2  
GND

Right Encoder  
VCC  
1  
2  
GND

Left Motor  
+5V  
PWM Speed  
Direction  
CUR  
GND

Right Motor  
+5V  
PWM Speed  
Direction  
CUR  
GND

Gnd  
+3V3, 500mA Out  
Gnd  
+5V, 1000mA Out  
Gnd  
+UB

IR LED 3

IR Sensor 3

Recharge LED

Power LED

Battery Recharge  
9V-12V DC

IR Sensor 4

IR LED 4

