

Codes télécommande GT017

Haut	FF629D
Bas	FFA857
Gauche	FF22DD
Droite	FFC23D
OK	FF02FD
1	FF6897
2	FF9867
3	FFB04F
4	FF30CF
5	FF18E7
6	FF7A85
7	FF10EF
8	FF38C7
9	FF5AA5
*	FF42BD
0	FF4AB5
#	FF52AD